

E5776	s-32 FAQ2
Q1:	Main Features of E5776s-32:
Q2:	Hardware specifications of E5776s-32:
Q3:	<b>Keys, Interface of E5776s-32</b>
Q4:	What information displayed on E5776s-32's OLED screen?
Q5:	The AutoPlay dialog box does not appear when connect E5776s-32 to PC with USB cable $\boldsymbol{6}$
Q6:	Check whether E5776s-32 has been successfully installed7
Q7:	Establish WiFi connection between PC and E5776s-329
Q8:	My device connected to E5776s-32's wireless network, but cannot open Web UI $10$
Q9:	E5776s-32's signal is weak and cannot register to 3G network
Q10:	E5776s-32's Wi-Fi signal is always weak
Q11:	Default encryption method of E5776s-32
Q12:	I forget my Wi-Fi key and Web login password I can't login my E5776s-3213
Q13:	How long it may take to fully charge E5776s-32 and how long E5776s-32 can work by
using	the fully charged battery?14
Q14:	I feel my E5776s-32 getting hot after long hours usage. Is there safety concern?15
Q15:	How can I get version information of my E5776s-32?
Q16:	Duration statistics of the Internet connection are not accurate16
Q17:	Will the Mobile WiFi connect to the Internet automatically if I roam to a different
netwo	ork?16
Q18:	Clients connected to the Mobile WiFi cannot communicate with each other17



# E5776s-32 FAQ

### Q1: Main Features of E5776s-32:

### A:

The E5776s-32 mainly supports the following features:

- DC-HSPA+ (DL) data service of up to 43.2 Mbit/s
- DC-HSPA+ (UL) data service of up to 5.76 Mbit/s
- HSPA+ (DL) data service of up to 21.6 Mbit/s
- HSPA+ (UL) data service of up to 5.76 Mbit/s
- HSDPA (DL) data service of up to 14.4 Mbit/s
- HSUPA (UL) data service of up to 5.76 Mbit/s
- UMTS data service of up to 384 kbit/s
- EDGE data service of up to 236.8 kbit/s
- GPRS data service of up to 85.6 kbit/s
- PS domain data service based on UMTS and GSM
- SMS based on CS/PS domain of GSM and UMTS
- Wi-Fi and WPS
- Plug and Play (PnP)
- 3G/Wi-Fi auto offload (optional)
- IPv6 /IPv4 dual stack (optional)
- Display current SSID and Wi-Fi key on the screen
- Built-in DHCP Server, DNS RELAY and NAT
- Online software upgrade
- Traffic statistic
- Standard Micro USB interface
- TFT-LCD screen
- Built-in UMTS and WLAN high gain antenna
- Windows XP, Windows Vista, Windows 7, MAC OS X 10.5, 10.6 and 10.7



### Q2: Hardware specifications of E5776s-32:

### A:

Item	Specifications		
Technical standard	WAN: DC-HSPA+/HSPA+/HSPA/UMTS/EDGE/GPRS/GSM     WLAN: IEEE 802.11b/g/n		
Operating	DC-HSPA+/HSPA+/HSPA/UMTS: 2100/900 MHz		
trequency	EDGE/GPRS/GSM: 190	00/1800/900/850 MHz	
	WLAN: 2400–2483.5 M	Hz	
Internal memory	128 MB Flash, 64 MB Me	emory	
Maximum	UMTS: 24 (+1/-3) dBm		
power	WLAN	802.11b: 14 (+/-3) dBm	
		802.11g: 11 (+/-3) dBm	
		802.11n: 9 (+/-3) dBm	
Receiver	UMTS: -106 dBm		
Sensitivity	WLAN 802.11b	-76 dBm@11 Mbit/s	
		-82 dBm@1 Mbit/s	
	WLAN 802.11g: -65 dBm@54 Mbit/s		
	WLAN 802.11n: -64 dBm@65 Mbit/s		
WLAN speed	802.11b: Up to 11 Mbit/s		
	802.11g: Up to 54 Mbit/s		
	802.11n: Support MCS0–MCS7; Up to 72.2 Mbit/s.		
Maximum power consumption	3.5 W		
Power supply • AC: 100–240 V			
	• DC: 5 V, 2 A		
Battery	<ul> <li>Type: Li (Rechargeable and irremovable)</li> <li>Capacity: 2.7 \/, 2000 mAb</li> </ul>		
	Capacity: 5.7 V, 5000 man     Maximum working time: 10 hours		
	<ul> <li>Maximum standby time: 500 hours while Wi-Fi is off; 60 hours while Wi-Fi is often on.</li> </ul>		
External	USB interface: Micro USB		
Interfaces	Standard microSD card interface		



E5776s-32 FAQ

Item	Specifications		
	SIM card: standard 6-pin SIM card interface		
	External main diversity antenna interface		
Screen	TFT-LCD		
Button	Power switch, WPS switch, Reset switch		
Antenna	<ul> <li>Built-in GSM/UMTS main diversity antenna</li> <li>Built-in UMTS diversity antenna</li> <li>Built-in WLAN antenna</li> </ul>		
Dimensions (D × W × H)	101.8 mm×65.8 mm×14.5 mm		
Weight	about 150 g (including the battery)		
Temperature• Operating: 0°C to +35°C• Storage: -20°C to +60°C			
Humidity	5% to 95% ( non-condensing)		



### Q3: Keys, Interface of E5776s-32



### Q4: What information displayed on E5776s-32's OLED screen?

A: Information you can read from the OLED screen of E5776s-32 showed below:





### • Signal strength

, , , , , , , , , , , , , , Signal strength from weak to strong.

### O Network type

- 2G/3G/4G: Connected to a 2G/3G/LTE network.
- R: Data roaming turned on.

### 🕑 Wi-Fi

- Wi-Fi turned on.
- Number of connected Wi-Fi devices.

### Battery Battery

Battery level from low to high.

### 6 SMS

- New messages.
- Number of new messages.

### **6** Network connection status

Internet connection is set up.

### Traffic statistics

- Data traffic information.
- Connection time.

### Note:

Data traffic information is for your reference only. For more accurate data traffic information, please consult your service provider.

### Q5: The AutoPlay dialog box does not appear when connect

### E5776s-32 to PC with USB cable

### A:

1. Please check if the computer OS meets one of the following:

- (1) Windows XP / Windows Vista / Windows 7
- (2) MAC OS X 10.5, MAC OS X 10.6, MAC OS X 10.7
- 2. Make sure E5776s-32 is turned on (OLED screen has lighten up and have WiFi icon has displayed

information as Q4). To turn on E5776s-32, hold and press "Power Key $\mathcal{O}$ " for 3 second. If E5776s-32 is out of battery power, please charge it by USB cable or power adaptor.



3. Find the drive path Mobile WiFi. It should appear as one virtual CD-ROM drive in . Double

click **Mobile WiFi** to open the folder of "E5776s-32", double click "LaulAutoRun.exe" to install

E5776s-32 and drivers manually.



4. If the drive path Mobile WiFi not showing up, make sure there is no damage on USB cable and no contamination at PC USB connectors. Try to re-plug in USB connectors (both end of USB cable) to E5776s-32 and computer again.

### Q6: Check whether E5776s-32 has been successfully installed





the "Computer Management" Click " Device Manager" ". If E5776s-32 has been installed successfully, You

would see one new "com port" and "HUAWEI Mobil Connect - Network Adapter" displayed

in 🚇 Device Manager



If "HUAWEI Mobil Connect – Network Adapter" shows ᄤ, right click it then select "Uninstall". Re-load the

network driver for E5776s-32 by right click P Network adapters , then select "Scan for hardware changes".



### Q7: Establish WiFi connection between PC and E5776s-32

A: Please follow	these st	teps to	set up	your	WLAN
------------------	----------	---------	--------	------	------

- 1. Enable your wireless network card and double click 📝 icon displayed on windows start bar to open
  - "Choose a wireless network" dialog
- 2. Select SSID of E5776s-32 in the local wireless device list (The WiFi Key and the SSID can be found on a label

	Connect	
stick inside the back cover), click 🎍	-	' to



3. Input WiFi Key in the dialog of password input then click **Connect** to establish connection(The WiFi Key and the SSID can be found on a label stick inside the back cover)

VIFI Key and the SSID can be found on a label stick inside the back cover)

Wireless Network Connection				
The network requires a network key (also called a WEP key or WPA key). A network key helps prevent unknown intruders from connecting to this network. Type the key, and then click Connect.				
Network key:	•••••			
Confirm network key:	•••••			
		Cancel		





4. After the icon of wireless network card turned from 🔜 (status of acquiring IP address ) into

, your PC has established WiFi connection with E5776s-32 successfully, enter http://192.168.1.1 in web browser (ex. IE) to visit Web UI

# Q8: My device connected to E5776s-32's wireless network, but cannot open Web UI

### A:

- 1. Double is to check your wireless network connection on windows start bar. Make sure your device is connected with your E5776s-32 not other Wi-Fi device.
- Open Web Browser from your device (ex. Microsoft Internet Explorer). Go <u>http://192.168.1.1</u> to open E5776s-32's Web UI.





3. If Web Browser failed to bring you to Web UI, click "Tool" from Browser then select "Internet Options".



Select "Connections" tab, then click "LAN settings".

Internet Options	? 🔀
General Security Privacy Content Connections	Programs Advanced
To set up an Internet connection, click Setup.	Setup
Dial-up and Virtual Private Network settings	
Cricket Broadband Network	A <u>d</u> d
Juawei	<u>R</u> emove
	Settings
Choose Settings if you need to configure a proxy server for a connection.	
• Never dial a <u>c</u> onnection	
O Dial whenever a network connection is not pre	sent
Always dial my default connection	
Current None	S <u>e</u> t default
Local Area Network (LAN) settings	
LAN Settings do not apply to dial-up connections. Choose Settings above for dial-up settings.	LAN settings
ОК	ancel Apply

For the "Local Area Network (LAN) Settings" pop-up, uncheck the top three check-boxes. Then click "OK" to apply changes.

Local Area Network (LAN) Settings
Automatic configuration     Automatic configuration     Automatic configuration     Automatic configuration     automatic configuration     Automatic configuration gript     Adorcess
Proxy server Use a proxy server for your LAN (These settings will not apply to did-up or VFN connections). Address: us2.happyhour.tP port: 8080 Advanced
Bypass proxy server for local addresses      OK Cancel

Refresh the Web Browser to show E5776s-32 management console page.



### Q9: E5776s-32's signal is weak and cannot register to 3G network

#### A:

 Please check local network condition, check whether there is 3G network which provided by telecom operator at the moment. Ensure you are not in some close environment. (You may check the signal strengthen by the icon and displayed on Web UI main page)



- 2. Please move E5776s-32 toward to window to get better signal
- 3. If the network condition is good but still cannot register, please try to reset E5776s-32 and try again
- 4. Sometimes E5776s-32 will be rejected by the operator for some reasons. Please reset E5776s-32 and check.
- If E5776s-32 still cannot camp on the network, please contact with your device provider.
- 5. Login Web UI to check whether E5776s-32 has been set to 2G only mode. If your E5776s-32 has been set to

2G only, please select the 3G only option in the drop down menu.

Home Statistics	SMS = U	Ipdate : Settings : Mo	re :
Quick Setup		Network Setting	as
Dial-up	0		
Mobile Connection		Network	
Profile Management		Preferred mode:	2G only
→Network Settings		Network Search	Auto
WLAN	0	Mode:	2G only 3G only
Security	0		4G only
System	0		
			Apply

### Q10: E5776s-32's Wi-Fi signal is always weak

A:



- When E5776s-32 using it's battery power, in order to save energy for longer run-time E5776s-32 will lower down its transmit power ,so Wi-Fi signal is weaker compare with powered by USB or power adapter. Connect E5776s-32 to power adapter or with USB cable to a running computer's USB port will enhance E5776s-32's Wi-Fi signal strength.
- Keep E5776s-32 at least 3 to 6 feet away from other electrical devices which may create RF signal and cause interference (for example, microwave oven, TVs, cordless/cellular phones, baby monitors or wireless speakers). If you needn't using any of those devices when you want to connect Internet, please turn it off.
- 3. In actual use Wi-Fi covered range maybe different from idea square area, it decided by the environment you use. The closer to E5776s-32, the stronger Wi-Fi signal you get. And every obstacle (walls, ceilings, furniture) between your device and E5776s-32 may decrease Wi-Fi signal strength. Move your device closer to E5776s-32 can avoid obstacles and improve Wi-Fi signal.

### Q11: Default encryption method of E5776s-32

### A:

E5776s-32 support following encryption method

- 1. SHARE authentication mode: WEP /NONE
- 2. WPA-PSK authentication mode: AES/TKIP/AES+TKIP
- 3. WPA2-PSK authentication mode: AES/TKIP/AES+TKIP
- 4. WPA/WPA2-PSK authentication mode: AES/TKIP/AES+TKIP

The default encryption method of E5776s-32 is WPA/WPA2-PSK authentication mode: AES+TKIP

If you changed encryption method of E5776s-32 the Wi-Fi connection between PC and E5776s-32 will be disconnected, please enter the new Wi-Fi key (Wi-Fi key of the encryption you selected ) when you want to establish Wi-Fi connection.

## Q12: I forget my Wi-Fi key and Web login password I can't login my E5776s-32

A: If you forget your Web login password, you needn't to worry. Try to restore

your E5776s-32 as following step

1. Open the back cover of E5776s-32





E5776s-32 FAQ

2. Press and hold the RESET button until OLED screen is off then E5776s-32 will restart, after E5776s-32 has boot up all the password will be restored to default.

Notice: After restored E5776s-32 all the user settings will be restored to default settings.

If you only forget your WiFi Key, try to set the new WiFi key in the "WLAN Basic Setting" page, input new WIFI key directly in WPA Pre Shared Key bar or select show password option the view the password

Home Statistics	SMS	Update <b>Settings</b> More	
Quick Setup		WLAN Basic Sett	inas
Dial-up	0		
WLAN	0	WPS cannot be used if En	cryption mode is set to NONE, WPA-PSK or WEP.
→WLAN Basic Settings		If Encryption mode is set to	o WEP or TKIP, a wireless network adapter working only in 802.11n
WLAN Advanced Settings WLAN MAC Filter		mode may fail to access th	ne device.
WPS Settings		SSID:	MobileWiFi-a6d5
DHCP		802.11 authentication:	WPAWPA2-PSK
Security	0	Encryption mode:	AES+TKIP
System	0	WPA pre-shared key:	
		SSID Broadcast	<ul> <li>Snow password</li> <li>Enable</li> <li>Disable</li> </ul>
			Apply

### Q13: How long it may take to fully charge E5776s-32 and how long E5776s-32 can work by using the fully charged battery?

### A12:

1. Time to full charge E5776s-32 battery

Device off charged by AC charger: 3h

2. Maximum working time(Attention: It's depend on the network status and environment temperature):

Using battery and WI-FI enabled (with data transmission):10hours.

Using battery and WI-FI disabled (standby mode):500h

Some improper uses will influent the life of battery, for example: used under high/low temperature and

humid environment, leaving battery unused for long time, the battery be charged and discharged for too



many times

The environment temperature required by the battery is  $-20^{\circ}$ GO<sup>o</sup>Q the ideal value is  $35^{\circ}$ C the relative humidity is  $5^{\circ}$ GO<sup>o</sup>C the ideal value is  $55^{\circ}$ C , the battery life can reach 18 months.

## Q14: I feel my E5776s-32 getting hot after long hours usage. Is there safety concern?

### A:

Like most other electronic devices, E5776s-32 get hotter during charge or big data transfer. It is a quite normal phenomenon if working in regular office environment. Even if it works in hot environment, E5776s-32 will automatically power off if its temperature reach 60  $^{\circ}$  for safety protections. (Please don't use E5776s-32 in close environment; it will cause poor signal and high heat of your E5776s-32)

### Q15: How can I get version information of my E5776s-32?

A:			
Click	Settings	→ System	
, → Dev	ice Information		, then you can see software & hardware version of you
E5776s-	32.		



Home Statistics	SMS U	Update : Settings :	More
Quick Setup		Device Infor	mation
Dial-up	0		
WLAN	0	Device name:	E5776s
Security	0	IMEI:	866089010006522
System	0	IMSI :	460002319467197
→Device Information		My number:	Unknown
Restore Defaults		Hardware version:	CL2E5776SM
Reboot		Software version:	21.200.03.01.00
		Web UI version:	12.001.22.00.03
		MAC Address:	0C:37:DC:03:A6:D5
		WAN IP Address:	Unknown

### Q16: Duration statistics of the Internet connection are not accurate.

A: This is a bug in earlier versions. You can click Clear History to delete all current wrong statistics.

#### **Statistics**

Туре	Current Volume	Total Volume
Download	387 B	66.76 KB
Upload	539 B	66.61 KB
Total	926 B	133.36 KB
Duration	00:00:35	00:21:09

Volume statistics provided here are approximate. For accurate statistics and details of charges refer to your bills.

Clear History

### Q17: Will the Mobile WiFi connect to the Internet automatically if I roam to a different network?

A:

Please check the connection mode of your Mobile WiFi firstly.



Home Statistics	SMS U	pdate Settings More	
Quick Setup		Mobile Connection	
Dial-up	0		
→Mobile Connection		Mobile Connection:	
Profile Management		Connection mode:	Auto 💌
Network Settings			
WLAN	0	Max idla time (a):	Enable even when roaming
Security	0	wax. rule unite (3).	000
System	0		
			Apply

- Auto mode:
  - Automatically connect even when roaming is selected by default. If you roam to a different network with the Mobile WiFi, it will automatically disconnect an established network connection. If you need to access the Internet from the new network, you must re-establish a network connection.
  - If **Automatically connect even when roaming** is not selected, the established network connection will not be effected by roaming state of the network

# Q18: Clients connected to the Mobile WiFi cannot communicate with each other.

A: If access point (AP) isolation is enabled, clients connected to the Mobile WiFi cannot communicate with

each other. If AP isolation is disabled, clients connected to the Mobile WiFi can communicate with each other.

ome Statistics	SMS 🗉 U	Ipdate <b>Settings</b> More	1
Quick Setup		WLAN Advanced	Settings
Dial-up	0		
WLAN	0	Country	
WLAN Basic Settings		oounay.	
→WLAN Advanced Settings		Channel:	Auto
WLAN MAC Filter WPS Settings DHCP		802.11 Mode:	802.11b/g/n
Security	0	AP isolation:	Off
System	0	WLAN auto off:	Enable (Without external power)
		WLAN off time (Min):	10
		Wi-Fi bandwidth:	20
			Арр