NOVASCALE BLADE

Ethernet Expansion Card

Installation and User's Guide



REFERENCE 86 A1 98EM 00

NOVASCALE BLADE

Ethernet Expansion Card

Installation and User's Guide

Hardware

January 2005

BULL CEDOC
357 AVENUE PATTON
B.P.20845
49008 ANGERS CEDEX 01
FRANCE

REFERENCE 86 A1 98EM 00

The following copyright notice protects this book under Copyright laws which prohibit such actions as, but not limited to, copying, distributing, modifying, and making derivative works.

Copyright © Bull SAS 2005

Copyright © Intel Corporation 2004

Printed in France

Suggestions and criticisms concerning the form, content, and presentation of this book are invited. A form is provided at the end of this book for this purpose.

To order additional copies of this book or other Bull Technical Publications, you are invited to use the Ordering Form also provided at the end of this book.

Trademarks and Acknowledgements

We acknowledge the right of proprietors of trademarks mentioned in this book.

 $\mathsf{Intel}^{\mathbb{R}}$ and $\mathsf{Itanium}^{\mathbb{R}}$ are registered trademarks of Intel Corporation.

Windows® and Microsoft® software are registered trademarks of Microsoft Corporation.

 $\mathsf{UNIX}^{\circledR}$ is a registered trademark in the United States of America and other countries licensed exclusively through the Open Group.

 $\mathsf{Linux}^{\text{\tiny{\$}}}$ is a registered trademark of Linus Torvalds.

NovaScale Blade safety and regulatory information

■ NOTE

The service procedures are designed to help you isolate problems. They are written with the assumption that you have model-specific training on all computers, or that you are familiar with the computers, functions, terminology, and service information provided in this manual.

Important Safety Instructions

Read all caution and safety statements in this document before performing any of the instructions. Read the manual *NovaScale Blade Series Boards and Chassis Safety Information*.

Consignes de sécurité

Lisez attentivement toutes les consignes de sécurité et les mises en garde indiquées dans ce document avant de suivre toute instruction. Consultez le manuel *NovaScale Blade Series Boards and Chassis Safety Information*.

Wichtige Sicherhetshinweise

Lesen Sie zunächts sämtliche Warn- und Sicherheitshinweise in diesem Dokument, bevor Sie eine der Anweisungen ausführen. Beachten Sie auch dem Buch NovaScale Blade Series Boards and Chassis Safety Information.

Importanti istruzioni sulla sicurezza

Leggere attentamente tutte le istruzioni sulla sicurezza contenute nel presente documento prima di eseguire qualsiasi operazione. Vedere il manuale *NovaScale Blade Series Boards and Chassis Safety Information*.

Instrucciones de seguridad importantes

Lea todas las declaraciones de seguridad y precaución de este documento antes de realizar cualquira de las instrucciones. Vea el documento *NovaScale Blade Series Boards and Chassis Safety Information*.

General Safety

Follow these rules to ensure general safety:

- Observe good housekeeping in the area of the machines during and after maintenance.
- When lifting any heavy object:
 - 1. Ensure you can stand safely without slipping.
 - 2. Distribute the weight of the object equally between your feet.
 - 3. Use a slow lifting force. Never move suddenly, or twist, when you attempt to lift.
 - 4. Lift by standing or by pushing up with you leg muscles; this action removes the strain from the muscles in your back. Do not attempt to lift any object that weighs more than 16 kg (35lb) or any object that you think is too heavy for you.
- Do not perform any action that causes hazards to the customer, or makes the equipment unsafe.
- Before you start the machine, ensure that other service representatives and the customer's personnel are not in a hazardous position.
- Place removed covers and other parts in a safe place, away from all personnel, while you are servicing the machine.
- Keep your tool case away from walk areas so that other people will not trip over it.
- Do not wear loose clothing that can be trapped in the moving parts of a machine. Ensure that your sleeves are fastened or rolled up above your elbows. If your hair is long, fasten it.
- Insert the ends of your necktie or scarf inside clothing, or fasten it with a nonconductive clip, approximately 8 centimeters (3 inches) from the end.
- Do not wear jewelry, chains, metal-frame eyeglasses, or metal fasteners for your clothing. **Remember:** Metal objects are good electrical conductors.
- Wear safety glasses when you are: hammering, drilling soldering, cutting wire, attaching springs, using solvents, or working in any other conditions that might be hazardous to your eyes.
- After service, reinstall all safety shields, guards, labels, and ground wires. Replace any safety device that is worn or defective.
- Reinstall all covers correctly before returning the machine to the customer.

Electrical Safety

CAUTION:

Electrical current from power, telephone, and communication cables can be hazardous. To avoid personal injury or equipment damage, disconnect the server system power cords, telecommunication systems, networks, and modems before you open the server covers, unless instructed otherwise in the installation and configuration procedures.

Important: Observe the following rules when working on electrical equipment.

- Use only approved tools and test equipment. Some hand tools have handles covered with a soft material that does not protect you when working with live electrical currents.
- Many customers have rubber floor mats (near their equipment) that contain small conductive fibers to decrease electrostatic discharges. Do not use this type of mat to protect yourself from electrical shock.
- Find the emergency power-off (EPO) switch, disconnect switch, or electrical outlet in the room. If an electrical accident occurs, you can quickly turn off the switch or unplug the power cord.
- Do not work alone under hazardous conditions, or near equipment that has hazardous voltages.
- Disconnect all power before:
 - Performing a mechanical inspection
 - Working near power supplies
 - Removing or installing main units
- Before you start to work on the machine, unplug the power cord. If you cannot unplug it, ask the customer to power-off the wall box (that supplies power to the machine) and to lock the wall box in the off position.
- If you need to work on a machine that has exposed electrical circuits, observe the following precautions:
 - Ensure that another person, familiar with the power-off controls, is near you. Remember: another person must be there to switch off the power, if necessary.
 - Use only one hand when working with powered-on electrical equipment; keep the other hand in your pocket or behind your back.
 - Remember: There must be a complete circuit to cause electrical shock. By observing the above rule, you may prevent a current from passing through your body.
- When using testers, set controls correctly and use the approved probe leads and accessories for that tester.
- Stand on suitable rubber mats (obtained locally, if necessary) to insulate you from grounds such as metal floor strips and machine frames.
- Observe the special safety precautions when you work with very high voltages; these instructions are in the safety sections of the maintenance information. Use extreme care when measuring high voltages.
- Regularly inspect and maintain your electrical hand tools for safe operational condition.

- Do not use worn or broken tools and testers.
- Never assume that power has been disconnected from a circuit. First, check that it has been powered-off.
- Always look carefully for possible hazards in your work area. Examples of these hazards are moist floors, nongrounded power extension cables, power surges, and missing safety grounds.
- Do not touch live electrical circuits with the reflective surface of a plastic dental inspection mirror. The surface is conductive; such touching can cause personal injury and machine damage.
- When the power is on and power supply units, blowers and fans are removed from their normal operating position in a machine, do not attempt to service the units. This practice ensures correct grounding of the units.
- If an electrical accident occurs, use caution:
 - Switch power off
 - Send another person to get help/medical aid

Handling electrostatic discharge-sensitive devices

Any computer part containing transistors or integrated circuits (IC) should be considered sensitive to electrostatic discharge (ESD). ESD damage can occur when there is a difference in charge between objects. Protect against ESD damage by equalizing the charge so that the server, the part, the work mat, and the person handling the part are all at the same charge.

■ NOTE

Use product-specific ESD procedures when they exceed the requirements noted here. Make sure that the ESD-protective devices you use have been certified (ISO 9000) as fully effective.

When handling ESD-sensitive parts:

- Keep the parts in protective packages until they are inserted into the product.
- Avoid contact with other people.
- Wear a grounded wrist strap against your skin to eliminate static on your body.
- Prevent the part from touching your clothing. Most clothing is insulative and retains a charge even when you are wearing a wrist strap.
- Use the black side of a grounded work mat to provide a static-free work surface. The mat is especially useful when handling ESD-sensitive devices.
- Select a grounding system, such as those in the following list, to provide protection that meets the specific service requirement.

■ NOTE

The use of a grounding system is desirable but not required to protect against ESD damage. Attach the ESD ground clip to any frame ground, ground braid, or green-wire ground.

Use an ESD common ground or reference point when working on a double-insulated or battery-operated system. You can use coax or connector-outside shells on these systems.

Use the round ground-prong of the AC plug on AC-operated computers.





DANGER

Electrical current from power, telephone and communication cables is hazardous.

To avoid a shock hazard:

- Do not connect or disconnect any cables or perform installation, maintenance, or reconfiguration of this product during an electrical storm.
- Connect all power cords to a properly wired and grounded electrical outlet.
- Connect to properly wired outlets any equipment that will be attached to this product.
- · When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- Disconnect the attached power cords, telecommunications systems, networks, and modems before you open the device covers, unless instructed otherwise in the installation and configuration procedures.
- Connect and disconnect cables as described in the following table when installing, moving, or opening covers on this product or attached devices.

To Connect	To Disconnect	
Turn everything OFF.	1. Turn everything OFF.	
2. First, attach all cables to devices.	2. First, remove power cords from outlet.	
3. Attach signal cables to connectors.	3. Remove signal cables from connectors.	
4. Attach power cords to outlet.	4. Remove all cables from devices.	
5. Turn device ON.		



CAUTION:

If your system has a module containing a lithium battery, replace it only with the same or an equivalent type battery recommended by the manufacturer. If your system has a module containing a lithium battery, replace it only with the same module type made by the same manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

Do not:

- · Throw or immerse into water
- Heat to more than 100°C (212°F)
- Repair or disassemble

Dispose of the battery as required by local ordinances or regulations.



CAUTION:

When laser products (such as CD-ROMs, DVD-ROM drives, fiber optic devices, or transmitters) are installed, note the following:

- Do not remove the covers. Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.




DANGER

Some laser products contain an embedded Class 3A or Class 3B laser diode. Note the following:

Laser radiation when open. Do not stare into the beam, do not view directly with optical instruments, and avoid direct exposure to the beam.







≥32 kg (70.5 lbs)



≥55 kg (121.2 lbs)



Use safe practices when lifting.





CAUTION:

The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



CAUTION:

Do not place any object weighing more than 82 kg (180 lbs.) on top of rack-mounted devices.







CAUTION:

Do not place any object weighing more then 82 kg (180lbs.) on top of rack-mounted devices.



CAUTION:

To avoid personal injury, before lifting the unit, remove all the blades to reduce the weight.





CAUTION:

Hazardous energy is present when the blade is connected to the power source. Always replace the blade cover before installing the blade.

Regulatory specifications and disclaimers

Safety compliance:	
USA:	UL 60950 - 3rd Edition/CSA 22.2. No. 60950
Canada:	cUL certified - 3rd Edition/CSA 22.2. No. 60950- for Canada (product bears the single cUL mark for U.S. and Canada)
Europe:	Low Voltage Directive, 73/23/EEC
	TUV/GS to EN60950 2nd Edition with Amendments, A1 = A2+A3+A4
International:	UL/CB to IEC 60950 3rd Edition
	UL/CB - EN60 950 3rd Edition
	UL/CB - EMKO-TSE (74-SEC) 207/94
Australia/New Zealand:	CB Report to IEC 60950, 3rd Edition plus international deviations

Electromagnetic compatibility (ECM)			
USA:	FCC CFR 47 Part 2 and 15, Verified Class A Limit		
Canada:	IC ICES-003 Class A Limit		
Europe:	EMC Directive, 89/336/EEC		
	EN55022, Class A Limit, Radiated & Conducted Emissions		
	EN55024 ITE Specific Immunity Standard		
	EN61000-4-2 ESD Immunity (Level 2 Contact Discharge, Level 3 Air Discharge)		
	EN61000-4-3 Radiated Immunity (Level 2)		
	EN61000-4-4 Electrical Fast Transient (Level 2)		
	EN61000-4-5 AC Surge		
	EN61000-4-6 Conducted RF		
	EN61000-4-8 Power Frequency Magnetic Fields		
	EN61000-4-11 Voltage Dips and Interrupts EN6100-3-3 Voltage Flicker		
Japan:	VCCI Class A ITE (CISPR 22, Class A Limit) IEC 1000-3-2 Limit for Harmonic Current Emissions		
Australia/New Zealand:	AS/NZS 3548, Class A Limit		
Taiwan:	BSMI Approval		
Korea:	RRL Approval		
Russia:	GOST Approval		
International:	CISPR 22, Class A Limit		

Electromagnetic compatibility notices (USA)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

■ NOTE

Class A device definition: If a Class A device is installed within the is system, then the system is to be considered a Class A system. In this configuration, operation of this equipment in a residential area is likely to cause harmful interference.

■ NOTE

This product is intended to be installed with CAT5 cable, or equivalent, to minimize electrical interference.

Electromagnetic compatibility notices (International)

Europe (CE Declaration of Conformity): This product has been tested in accordance too, and complies with the Low Voltage Directive (73/23/EEC) and EMC Directive (89/336/EEC). The product has been marked with the CE Mark to illustrate its compliance.

Japan EMC Compatibility:

この装置は、情報処理装置等電波障害自主規制協議会(VCCI)の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

English translation of the notice above: This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

ICES-003 (Canada): Cet appareil numérique respecte les limites bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques", NMB-003 édictée par le Ministre Canadian des Communications.

English translation of the notice above: This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of the Canadian Department of Communications.

BSMI (**Taiwan**): The BSMI Certification number and the following warning is located on the product safety label which is located visibly on the external chassis.

警告使用者:

這是甲類的資訊產品,在居住的環境中使用時, 可能會造成射頻干擾,在這種情況下,使用者會 被要求採取某些適當的對策。

RRL Korea:

기 종 별	사 용 자 안 내 문
A급 기기	이 기기는 업무용으로 전자파 적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며 만 약 잘못판매 또는 구입하였을 때에는 가정용으로 교환 하시기 바랍니다.
B급 기기	이 기기는 가정용으로 전자파 적합등록을 한 기기로서 주거지역에서는 물론 모든 지역에서 사용할 수 있습니다.

※ 비고

A급 기기 : 업무용 정보통신기기를 말한다. B급 기기 : 가정용 정보통신기기를 말한다.

English translation of the notice above:

Device	User's Information	
Class A device	This device complies with RRL EMC and is operated in commercial environment so that distributors or users pay attention to this point. If the product is sold or purchased improperly, please	
	exchange this product to what can be used at home.	
Class B device	This device complies with RRL EMC and is operated in a residential area so that it can be used at all other location as well as residential area.	
note: Class A device: operated in a commercial area. Class B device: operated in a residential area.		

<This page intentionally left blank>

Contents

1	Introduction Related publications. Features and specifications. Inventory checklist. Notices and statements used in this book.	1 1 2
2	Installing the Gigabit Ethernet I/O expansion card. Installation guidelines. Handling static-sensitive devices. Installing the expansion card	3
3	Troubleshooting	5
Α	Getting help and technical assistance	7
	Before you call	7

1 Introduction

This *Installation Guide* contains instructions about installing and configuring your NovaScale Blade Ethernet Expansion Card in a NovaScale Blade SCSI Expansion Module.

The NovaScale Blade Ethernet Expansion Card has a dual-channel integrated Gigabit Ethernet controller capable of connecting to 10/100/1000-Mbps networks through an Ethernet switch module, or other supported I/O modules, on the NovaScale Blade Chassis unit. Communication signals are routed from the NovaScale Blade Server through the I/O expansion connectors on the expansion card to I/O-module bay 3 and bay 4 in the NovaScale Blade Chassis unit.

■ NOTE

The modules in I/O-module bay 3 and bay 4 in the NovaScale Blade Chassis unit must both be the same and must both be compatible with the expansion card.

The expansion card is available in two sizes; standard-form factor and small-form factor.

Related publications

This *Installation Guide* contains setup and installation instructions for your I/O expansion card, including information about getting started and how to configure your I/O expansion card. In addition to this *Installation Guide*, the following related documentation is provided with your NovaScale Blade Server:

- NovaScale Blade 2021 Installation and User's Guide
 This document contains instructions for setting up and configuring the NovaScale Blade 2021 blade and basic instructions for installing some options. It also contains general information about the NovaScale Blade 2021blade unit.
- NovaScale Blade 2021 Hardware Maintenance Manual and Troubleshooting Guide

 This document contains information to help you solve problems yourself. It also contains information for service technicians.

Features and specifications

The expansion card has the following features:

- Connection to 1000BASE-TX environments
- Compliance with U.S. and international safety and emissions standards
- Full-duplex (FDX) capability, enabling simultaneous transmission and reception of data on the Ethernet local area network (LAN)
- Wake on LAN* support
- Failover support
- Preboot Execution Environment (PXE) support

Inventory checklist

The expansion card option package contains the NovaScale Blade Ethernet Expansion Card.

For updated information about configuring your NovaScale Blade Ethernet Expansion Card, contact your Bull representative.

Notices and statements used in this book

The following types of notices and statements are may be used in this book:

- Note: These notices provide important tips, guidance, or advice.
- **Important:** These notices provide information or advice that might help you avoid inconvenient or problem situations.
- **Attention:** These notices indicate possible damage to programs, devices, or data. An attention notice is placed just before the instruction or situation in which damage could occur.
- Caution: These statements indicate situations that can be potentially hazardous to you. A caution statement is placed just before the description of a potentially hazardous procedure step or situation.
- **Danger:** These statements indicate situations that can be potentially lethal or extremely hazardous to you. A danger statement is placed just before the description of a potentially lethal or extremely hazardous procedure step or situation.

2 Installing the Gigabit Ethernet I/O expansion card

This chapter provides details about installing the Gigabit Ethernet I/O expansion card.

The I/O expansion card comes in two form factors (standard-form factor and small-form factor) and can be installed in a NovaScale Blade Server and a storage expansion unit.

Installation guidelines

Before you begin installing the I/O expansion card in your NovaScale Blade Server, read the safety information beginning on page iii and the guidelines in "Handling static-sensitive devices" below. This information will help you work safely with your NovaScale Blade Server and options.

Handling static-sensitive devices

Attention: Static electricity can damage electronic devices, including your NovaScale Blade Server. To avoid damage, keep static-sensitive devices in their static-protective packages until you are ready to install them.

To reduce the possibility of damage from electrostatic discharge, observe the following precautions:

- Limit your movement. Movement can cause static electricity to build up around you.
- Handle the device carefully, holding it by its edges or its frame.
- Do not touch solder joints, pins, or exposed circuitry.
- Do not leave the device where others can handle and damage it.
- While the device is still in its static-protective package, touch it to any *unpainted* metal surface of the NovaScale Blade Chassis or any *unpainted* metal surface on any other grounded rack component in the rack you are installing the device in for at least 2 seconds. (This drains static electricity from the package and from your body.)
- Remove the device from its package and install it directly into the NovaScale Blade Server
 without setting down the device. If it is necessary to set down the device, place it back into its
 static-protective package. Do not place the device on your NovaScale Blade Server cover or on a
 metal surface.
- Take additional care when handling devices during cold weather. Heating reduces indoor humidity and increases static electricity.

Installing the expansion card

See your NovaScale Blade 2021 documentation for detailed instructions about installing the standard-form factor and small-form factor I/O expansion cards.

3 Troubleshooting

If you are having a problem, use the following information to help you determine the cause of the problem and the action to take. Additional troubleshooting and debugging procedures are available in the *Hardware Maintenance Manual and Troubleshooting Guide* for your NovaScale Blade Server. This guide is available on the Resource CD that comes with the NovaScale Blade Server.

Make sure you are using the latest versions of device drivers, firmware, and BIOS for your NovaScale Blade Server and management module. If these items are obsolete, the NovaScale Blade Chassis unit might not recognize the expansion card and might not turn it on. Contact your Bull representative for the latest information about upgrading the device drivers, firmware, and BIOS for NovaScale Blade Chassis components. The latest instructions are in the documentation that come with the updates.

To determine whether your installation problem is caused by the hardware, perform the following tasks:

- Verify that the expansion card is installed correctly.
- Verify that all peripheral devices connected to the I/O modules are turned on, operating properly, and are properly connected.
- Verify that the I/O modules used by the expansion card are installed in the correct I/O-module bays of the NovaScale Blade Chassis unit.

To determine whether your installation problem is caused by the software, verify that the correct Ethernet device driver is installed. The NovaScale Blade Ethernet Expansion Card uses new Ethernet device drivers that are compatible with the integrated Ethernet controllers on the NovaScale Blade Server system board. To get information about the latest supported device drivers, utilities, and documentation, contact your Bull representative. Also see the *Installation and User's Guide* for your NovaScale Blade Server on the Resource CD that comes with the NovaScale Blade Server.

To determine whether your installation problem is caused by the system configuration, check the Ethernet configuration settings using the NovaScale Blade Server Configuration/Setup Utility program. See the *Installation and User's Guide* for your NovaScale Blade Server on the Resource CD that comes with the NovaScale Blade Server for additional information.

If you still have a system configuration problem, see the documentation that comes with your NovaScale Blade Chassis unit, or contact your technical-support representative to determine whether your system board requires a special configuration.

A Getting help and technical assistance

If you need help, technical assistance, or just want more information about NovaScale Blade products, you will find a wide variety of sources available from Bull to assist you. This appendix contains information about where to go for additional information about Bull and Bull products, what to do if you experience a problem with your NovaScale Blade server system.

Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system is turned on.
- Use the troubleshooting information in your system documentation, and use the diagnostic tools
 that come with your system. Information about diagnostic tools is in the *Hardware Maintenance*Manual and Troubleshooting Guide on the Resource CD that came with your NovaScale Blade
 Server or NovaScale Blade Chassis.

You can solve many problems without outside assistance by following the troubleshooting procedures in the publications that are provided with your system and software. The information that comes with your system also describes the diagnostic tests that you can perform. Most systems and programs come with information that contains troubleshooting procedures and explanations of error messages and error codes.

Using the documentation

Information about your NovaScale Blade Ethernet Expansion Card is available in the documentation that comes with your system. That documentation may include printed books, online books, readme files, and help files. See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. Contact your support representative to obtain the latest technical information and download device drivers and updates.

Getting help and information from Bull

Contact your Bull representative.

Index

C	I
configuration problems 5	I/O Expansion Card 1, 3
_	I/O expansion Card 1, 3
D	installation guidelines 3
description	installing the I/O expansion card 3
expansion card 1	inventory checklist 2
E	N
expansion card	notices and statements 2
description 1	NovaScale Blade Chassis unit 1
features 1	_
installing the I/O expansion card 3	R
_	related publications 1
F	_
features and specifications 1	
	troubleshooting
Н	hardware 5
handling static-sensitive devices 3	installation problems 5
hardware problems 5	system configuration problems 5

Technical publication remarks form NOVASCALE BLADE Ethernet Expansion Card Installation and User's Guide Title: Reference N°: 86 A1 98EM 00 Date: January 2005 **ERRORS IN PUBLICATION** SUGGESTIONS FOR IMPROVEMENT TO PUBLICATION Your comments will be promptly investigated by qualified technical personnel and action will be taken as required. If you require a written reply, please include your complete mailing address below. NAME : ______ Date : _____ COMPANY: ADDRESS : _____

Please give this technical publication remarks form to your BULL representative or mail to:

Bull - Documentation D^{ept.}
1 Rue de Provence
BP 208
38432 ECHIROLLES CEDEX
FRANCE
info@frec.bull.fr

Technical publications ordering form

To order additional publications, please fill in a copy of this form and send it via mail to:

BULL CEDOC 357 AVENUE PATTON B.P.20845 49008 ANGERS CEDEX 01 FRANCE

CEDOC Reference #	Designation	Qty
[]		
[]		
[]		
[]		
[]		
[]		
[]		
[]		
[] : The latest revision will b	pe provided if no revision number is given.	

Phone:

FAX: E-Mail: +33 (0) 2 41 73 72 66 +33 (0) 2 41 73 70 66 srv.Duplicopy@bull.net

NAME:	Date:	
COMPANY:		
ADDRESS:		
PHONE:		
E-MAIL:		
For Bull Subsidiaries: Identification:		
For Bull Affiliated Customers: Customer Code:		
For Bull Internal Customers: Budgetary Section:		

For Others: Please ask your Bull representative.

BULL CEDOC 357 AVENUE PATTON B.P.20845 49008 ANGERS CEDEX 01 FRANCE

REFERENCE 86 A1 98EM 00