```
*************************************************************
*
*  Gemalto e-gate USB smart card drivers
*       version 2.6.0.0
*
*  Installation Readme
*
*************************************************************



*************************************************************
*  CONTENTS OF THIS DOCUMENT
*************************************************************
This document contains the following sections:

1.  Overview
2.  System Requirements
3.  Contents of the Distribution Package
4.  List of Available Command Line Flag Options
5.  List of Available Return Codes
6.  Windows Server 2003 Installation notes




*************************************************************
* 1.  OVERVIEW
*************************************************************
The installation program will install to the target system
the drivers e-gate USB smart card devices.

If a previous version of these drivers is already installed,
the installer will update these drivers to the current version.

The default installation directory is :
     <PROGRAM FILES>\Axalto\egate driver 2.6.0.0




*************************************************************
* 2.  SYSTEM REQUIREMENTS
*************************************************************
This software is intended for the following Operating systems :
     Windows 2000, Windows XP
     Windows Server 2003.




*************************************************************
* 3.  CONTENTS OF THE DISTRIBUTION PACKAGE
*************************************************************
The e-gate USB smart card drivers installation package
contains the following items:

     File(s)
     -------
     EGATE-XP2K-SETUP.EXE (Windows 2000/XP)
     EGATE-SRV2K3-SETUP.EXE (Windows Server 2003)
     README.TXT (this file)
```

```
**************************************************************
* 4.  LIST OF AVAILABLE COMMAND LINE FLAG OPTIONS
**************************************************************
The installation program supports some command line flags
for installation options.

Flag               Description
----               -----------
/S                 Silent installation
                   A silent installer is an installer which requires
                   no user intervention and have no user interface.

/D=<Install Path> Overrides the default installation directory



**************************************************************
* 5.  LIST OF AVAILABLE RETURN CODES
**************************************************************
When the installation completes, the installation program returns
a return code which is one of the following :

  0                Normal execution (no error)
  1                Installation aborted by user
  2                The current platform is not supported
  3                Administration privileges are required
  4                For more information, see log file
  5                Unsupported error, see log file
  10 to 15         A system restart is required

When a sytem restart is required to complete the installation process,
the return code is increased by 10.

In addition, a logging file named "egateinstall.log" is created in the
installation directory.



**************************************************************
* 6.  WINDOWS SERVER 2003 INSTALLATION NOTES
**************************************************************
For Windows Server 2003 and later versions, if the device setup class of a
driver package is not included in the Windows Logo Program, this package
cannot obtain a WHQL digital signature and the publisher is responsible for
digitally signing the driver using the Microsoft Authenticode technology.

So, when the driver is installed, the publisher certificate is displayed and the
user must accept to trust the publisher to continue the installation.

In order to avoid this process during a silent installation, the administrator
can
add the publisher certificate to the system certificate store, before executing
the
setup program.
```